



H325MS, Install Guide (Landscape)




Step-1, fixed wall-frame




Step-2, H325MS install

Mount-holder Location




Caution) Screw points for mount-holder
(The points are different based on landscape and portrait installation)

Mount-holder Install Location




Caution) fixed position of the mount-holder

H325MS, Install Guide (Portrait)




Step-1, fixed wall-frame




Step-2, H325MS install

Mount-holder Location




Caution) Screw points for mount-holder
(The points are different based on landscape and portrait installation)

Mount-holder Install Location




Caution) fixed position of the mount-holder

Front Door Open & Remove Screw




Front View (Door open)

Dustproof Filter Exchange (Exploded view)



H325MS, LCD Panel Exchange & Board Repair

Caution) LCD Panel is released when you loose the screws.
Handle very carefully to prevent damage on the LCD Panel.





LVDS_Cable_Disconnect


Inverter_Cable_Disconnect

Step-2

Bottom view



Side view (Right)



Step-2, Cable disconnection.



Step-1, Front open

Step-3, Loose screw
(LCD Panel Ass'y)

Step-4, Loose screw
(LCD Panel)

Step-5, LCD Panel separation

remove this Screw
(Left & Right side - 4 Ea)



Rear view (LCD Panel Ass'y)

LCD_Panel_Bracket

LCD_Panel

PAD